



## INSTALLATION INSTRUCTIONS FOR ACRYLIC WINDOWS ON THE WALL OF THE CARAVAN AND MOTORHOME

When setting up windows on the caravan or motorhome we recommend following steps:

1. Screw aluminium bar on the wall approximately 16mm above the wall opening.
2. Place rubber profile and pvc strip on the wall opening.
3. Lift the window between 70 and 90° and slide in the window into the aluminium hinge moulding screwed onto the wall. One finger can be placed on the end cap so that can you feel how far the window needs to be pushed in.
4. After the window is in position, screw both profiles together. This way you will prevent the window from sliding out.
5. Screw window holder on rubber profile with screwdriver.
6. Screw catchers on rubber profile.

