

# MILENCO

## 2653 Handrail Frame Mounting Kit



**Check orientation and screw frame mounting kit to Security Handrail.**



**Apply sealant to base.**



**Drill 4 holes 4.5 dia.**



**Affix 4 x screws.**



**Check position of base and drill centrally.**



**Screw base from behind in 2 places.**

**Requires a minimum of 5mm gap between door and frame.**