

MILENCO

2066 Security Handrail Fitting



Use Gasket to mark drill position. Double check distance between top and bottom mounting points.



**Drill 2 x 4 holes
7mm diameter.**



Mount 2 inside backing plates and insert 8 screws.



**Fit 2 x Gaskets and then
tighten 8 x M6 screws.**



Fit 2 x Trim Cover Plates.



**Inside view of
mounting cover
Width: 90mm x Height:
105mm**