

KICKASS



INFLATABLE SOFA ARMCHAIR | OTTOMAN

OWNER'S MANUAL

KAINFSOFADUO | KAINFSOFASOLO | KAINFSTOOL

V1.1

SAFETY INFORMATION

- These products are designed for seated use only. Do not stand, jump or climb on them.
- Do not exceed the stated maximum load capacity for your model.
- Ensure the product is fully inflated before use to maintain stability and support.
- Do not over-inflate. Inflate only to the recommended operating pressure of 1 PSI/6.9 kPa.
- Keep away from sharp objects, rocks, sticks and abrasive surfaces that may puncture the inner bladder. Always aim to use the supplied ground mat with the sofa and armchair.
- Do not place near open flames, hot surfaces, heaters or campfires.
- Keep away from cigarettes, lighters and other ignition sources.
- Avoid prolonged exposure to extreme heat, as high temperatures may cause internal air expansion and damage.
- Use only on stable, level ground to reduce the risk of tipping.
- These products are not flotation devices. Do not use in water.
- Keep out of reach of children when inflating, deflating or charging the pump.
- Do not insert fingers or objects into valves or pump openings.
- Inspect the product before each use for signs of wear, punctures or damage. Do not use if damaged.
- Only use the supplied charging cable or a compatible manufacturer-approved cable for charging the pump.
- Do not operate the air pump while it is wet. Allow it to dry completely before use.
- Store in a cool, dry place away from direct sunlight when not in use.

TABLE OF CONTENTS

SAFETY INFORMATION ----- 2

SPECIFICATIONS ----- 3

 Inflatable Sofa - KAINFSOFADUO ----- 3

 Inflatable Armchair - KAINFSOFASOLO ----- 3

 Inflatable Ottoman - KAINFSTOOL ----- 4

INCLUDED COMPONENTS ----- 6

PRODUCT FEATURES ----- 8

PRODUCT OVERVIEW ----- 10

 INFLATABLE SOFA - KAINFSOFADUO ----- 10

 INFLATABLE ARMCHAIR - KAINFSOFASOLO ----- 11

 INFLATABLE OTTOMAN - KAINFSTOOL ----- 12

 ELECTRIC AIR PUMP ----- 12

CHARGING THE ELECTRIC AIR PUMP ----- 13

USING THE INFLATABLE SOFA & ARMCHAIR ----- 14

 SETUP ----- 14

 INFLATION ----- 14

 DEFLATION ----- 15

 STORAGE ----- 15

ADDITIONAL AIR PUMP FEATURES ----- 16

 LED LIGHT ----- 16

 ENHANCING MODE ----- 16

USING THE OTTOMAN ----- 17

 SETUP ----- 17

 INFLATION ----- 17

 DEFLATION ----- 17

CLEANING INSTRUCTIONS ----- 18

TROUBLESHOOTING ----- 19

WARRANTY & SUPPORT INFORMATION ----- 20

SPECIFICATIONS

KickAss Inflatable Sofa - KAINFSOFADUO

PRODUCT DIMENSIONS	Inflated: 1700 x 800 x 840 mm (L x W x H) Packed: 490 x 140 x 300mm
PRODUCT WEIGHT	6.6 kg
SEAT HEIGHT	400 mm
SEAT AREA	1300 x 600 mm
BACKREST LENGTH	1300 mm
ARMREST WIDTH	190 mm
FABRIC MATERIAL	600D Oxford cloth with UPF 50+
GROUND MAT DIMENSIONS	1710 x 840 mm
AIR CHAMBER DESIGN	Two PVC membrane chambers (upper and lower)

KickAss Inflatable Armchair - KAINFSOFASOLO

PRODUCT DIMENSIONS	Inflated: 990 x 800 x 840 mm (L x W x H) Packed: 90 x 155 x 350mm
PRODUCT WEIGHT	4.4 kg
SEAT HEIGHT	400 mm
SEAT AREA	600 x 600 mm
BACKREST LENGTH	620 mm
ARMREST WIDTH	190 mm
FABRIC MATERIAL	600D Oxford cloth with UPF 50+
GROUND MAT DIMENSIONS	1015 x 840 mm
AIR CHAMBER DESIGN	Two PVC membrane chambers (upper and lower)

KickAss Inflatable Ottoman - KAINFSTOOL

PRODUCT DIMENSIONS	Inflated: 750 x 590 x 400mm (L x W x H) Packed: 330 x 80 x 230 mm (L x W x H)
PRODUCT WEIGHT	1.2 KG
FABRIC MATERIAL	600D Oxford cloth with UPF 50+
COVER TYPE	Removable, machine washable
AIR CHAMBER DESIGN	0.3mm reinforced PVC chamber
MAXIMUM LOAD CAPACITY	120kg
INFLATION SYSTEM	Single high-flow valve
OPERATING PRESSURE	1 PSI

INCLUDED COMPONENTS

KickAss Inflatable Sofa - KAINFSOFADUO



Inflatable Sofa
Carry Bag
Rechargeable Air Pump
3 in 1 Air Pump Adaptors
USB-C Charging Cable
Ground Mat

KickAss Inflatable Armchair - KAINFSOFASOLO



Inflatable Armchair
Carry Bag
Rechargeable Air Pump
3 in 1 Air Pump Adaptors
USB-C Charging Cable
Ground Mat

KickAss Inflatable Ottoman - KAINFSTOOL



Inflatable Ottoman
Carry Bag

PRODUCT FEATURES

Integrated 4000mAh Air Pump – KAINFSOFADUO and KAINFSOFASOLO

The inflatable sofa and armchair feature a built-in 4000mAh rechargeable air pump for fast, hassle-free inflation and deflation. The integrated LED light allows easy setup even after dark.

Single High-Flow Valve – KAINFSTOOL

The inflatable ottoman uses a single high-flow valve for quick inflation and deflation. Its simple valve design makes setup fast and pack-down easy.

Dual Chamber Construction – KAINFSOFADUO and KAINFSOFASOLO

Both the Duo and Solo models use a dual chamber system to improve stability, structure and long-term durability while maintaining consistent comfort.

Single Chamber Construction – KAINFSTOOL

The ottoman features a single reinforced air chamber designed to provide stable leg support while keeping weight and pack size to a minimum.

Durable 600D Oxford Fabric Cover – All Models

Each model includes a removable 600D heavy-duty Oxford fabric cover designed to resist tearing, abrasions and general campsite wear. The cover is machine washable for easy cleaning.

UPF 50+ UV Protection – All Models

All models are constructed with UPF 50+ UV-resistant fabric to help prevent fading, cracking and premature wear caused by harsh sun exposure.

Splash-Proof Water-Repellent Coating – All Models

A splash-proof coating helps repel light rain, spills and ground moisture to keep the inner bladder protected during outdoor use.

Reinforced PVC Inner Bladder – Model Specific

- KAINFSOFADUO and KAINFSOFASOLO use 0.35 mm reinforced PVC for added strength and durability.
- KAINFSTOOL uses 0.3 mm reinforced PVC to maintain strength while reducing overall weight.

Ergonomic Inflated Dimensions – Model Specific

- KAINFSOFADUO inflates to 170 × 80 × 84 cm, providing spacious dual seating comfort.
- KAINFSOFASOLO inflates to 99 × 80 × 84 cm, offering structured single-seat support.
- KAINFSTOOL inflates to 75 × 59 × 40 cm, delivering optimal leg elevation and back pressure relief.

Lightweight and Portable Design – All Models

- KAINFSOFADUO weighs 6.6 kg for manageable transport.
- KAINFSOFASOLO weighs 4.4 kg for easy relocation.
- KAINFSTOOL weighs just 1.2 kg, making it highly portable and compact for travel.

Secure Storage Pocket – All Models

Each model includes a side storage pocket with Velcro flap, ideal for keeping phones, sunglasses, snacks and small essentials within easy reach.

Reinforced Carry Handles – All Models

A reinforced carry handle allows easy lifting, repositioning and transport, even when the product is fully inflated.



PRODUCT OVERVIEW

KICKASS INFLATABLE SOFA - KAINFSOFADUO



UPPER CHAMBER - ZIP COVER



LOWER CHAMBER - ZIP COVER

UNIVERSAL AIR PORT



LOWER CHAMBER AIR PUMP VALVE / UNIVERSAL AIR PORT



CARABINER ATTACHMENT

POCKETS

GROUND MAT



GROUND STAKE RING

KICKASS INFLATABLE ARMCHAIR - KAINFSOFASOLO




UPPER CHAMBER - ZIP COVER



LOWER CHAMBER - ZIP COVER



LOWER CHAMBER AIR PUMP VALVE / UNIVERSAL AIR PORT



GROUND MAT

CARABINER ATTACHMENT

POCKETS

GROUND STAKE RING

KICKASS INFLATABLE OTTOMAN - KAINFSTOOL




UNIVERSAL AIR PORT

CARRY HANDLE

POCKET

ELECTRIC AIR PUMP (INCLUDED WITH THE SOFA AND ARMCHAIR ONLY)



HANDLE

INFLATE BUTTON

POWER/ENHANCE BUTTON

DEFLATE BUTTON

NOZZLE ADAPTERS

USB-C CHARGING PORT

LED LIGHT BUTTON

CHARGING THE ELECTRIC AIR PUMP

INCLUDED WITH THE SOFA AND ARMCHAIR ONLY

Note: Make sure the air pump is fully charged before first use.

- Connect the supplied charging cable to the air pump's USB-C port.



- The charge indicator will illuminate red.



- Once the indicator turns blue signaling full charge, unplug the cable.



- The pump is now ready to be used.

Note: when in use, if the LED indicator flashes red, the battery is low and requires charging.

USING THE INFLATABLE SOFA & ARMCHAIR

SETUP

- Choose a flat, clean surface free from sharp objects.
- Place the protective ground mat on the surface before unfolding the sofa.
- Remove the inflatable from the carry bag and fully unfold it on top of the ground mat. Ensure fabric and air chambers are not twisted.



INFLATION

Lower Chamber

- Open the lower chamber zip valve cover located at the rear of the inflatable.
- You can inflate the lower chamber using either of the following methods:
 - Through the dedicated air pump slot:
 - Press the unlock button to open the slot and insert the included air pump.
 - Press POWER button then press INFLATE button to start inflating.
 - When the chamber reaches the desired firmness, press POWER button to turn it off.
 - Remove the pump and close the slot cover.
 - Through the universal air valve:
 - Attach the appropriate adapter to the universal airport.
 - Open the airport cover and insert the air pump with attachment.
 - Press POWER button then press INFLATE button to start inflating.
 - When the chamber reaches the desired firmness, press POWER button to turn it off.
 - Remove the pump and replace the valve cover.



Upper Chamber

- Open the zipper of the upper chamber and locate the upper chamber air valve.
- Attach the appropriate adapter to the air pump outlet.
- Open the manual valve cover and insert the air pump with attachment.
- Press POWER button then press INFLATE button to start inflating.
- When the chamber reaches the desired firmness, press POWER button to turn it off.
- Remove the pump and reattach the valve cover.
- Close the zipper of the upper chamber.



DEFLATION

- Open the valve covers on both chambers.
- Release air manually or use the pump's deflate function. Insert the air pump to each inlet valve and press POWER button then press DEFLATE button of the air pump. Switch off by pressing the POWER button once fully deflated.
- Use the air pump to deflate the other chamber.
- Close and secure both chambers.



STORAGE

- Once fully deflated, fold the sofa neatly and place it into the carry bag.
- Ensure the sofa is clean and completely dry before storage.
- Store in a cool, dry place away from direct sunlight.

ADDITIONAL AIR PUMP FEATURES

LED LIGHT

- Press and hold the LIGHT button to turn on the light (Low mode).
- Short press the LIGHT button to move through the following sequence:

OFF ► LOW ► HIGH ► PULSE ► OFF



ENHANCING MODE

You can top up your inflatable using the ENHANCE function. This operates as a pulse inflation option.

Simply press and hold the ENHANCE button to inflate, and release the button to stop.

Tip: Once you have inflated both the lower and upper chambers, reinsert the air pump into the lower chamber slot so you can easily top up your seat if needed.



USING THE OTTOMAN

SETUP

- Choose a flat, clean surface free from sharp objects.
- Unfold the camping stool. Ensure fabric and air chambers are not twisted.



INFLATION

- Unpeel the Velcro of the cover and insert on the handle to suspend.
- Remove the air valve cap and start inflating. You can use an electric pump, air blower, or manual pump.
- When the Ottoman reaches the desired firmness, remove the device for inflation and return the cap.
- Pull the inlet valve cover from the handle secure using the Velcro.



DEFLATION

- Open the valve cover and air valve cap.
- Release air manually by pressing the Ottoman to flat.
- If you have an electric pump, you can also remove air by using the deflate function.
- Fold and store to a dry place.



CLEANING INSTRUCTIONS

- Wipe the sofa dry with a soft cloth to remove dirt or spills and dry immediately with a clean towel.
- Do not use bleach, harsh detergents, or abrasive cleaners as they can damage the material.
- For stubborn stains, gently wipe the area with mild soap and water.
- Ensure the sofa is completely dry before folding or storing to prevent mold and mildew.
- Store in a cool, dry place away from direct sunlight when not in use.
- Do not submerge the sofa in water.

TROUBLESHOOTING

Air pump does not turn on	• If the LED indicator is flashing red, the pump is fully discharged and requires charge. Always charge the air pump to full before first use.
Sofa does not fully inflate	• Check that the correct air valve nozzle is attached and is securely connected. Improper connection may lead to inefficient inflating.
Sofa loses air over time	• Inspect the inlet valve cap if securely attached. • Inspect the surface and air chambers for puncture or damage.

WARRANTY & SUPPORT INFORMATION

KICKASS LIMITED WARRANTY

Your KickAss product is backed by our limited warranty against defects in materials and workmanship for the applicable warranty period. Warranty periods vary by product - please check the product page or the KickAss Warranty Index for details.

If a fault covered by warranty occurs, KickAss will, at its discretion:

- Repair the product, or
- Replace the product with the same or equivalent model, or
- Provide another suitable remedy in line with Australian Consumer Law (ACL).

Warranty claims may be declined if the issue is caused by:

- Normal wear and tear.
- Improper use, faulty installation, or lack of maintenance.
- Modifications, tampering, or unauthorised repairs.
- Accidents, damage in transit (customer organised), or environmental causes.
- Consumable items, unless defective in materials or workmanship.
- Damage caused by external events such as severe weather (including storms, lightning, hail, or flooding), fire, impact, explosions, vandalism, or theft.

MAKING A WARRANTY CLAIM

1. Visit our Support Portal: supportportal.kickassproducts.com.au
2. Locate your product via the Products & Troubleshooting section.
3. Submit a claim through the product form and follow the guidance from our Customer Service Team.

All warranty claims must include a completed product form, proof of purchase, and clear evidence of the defect or fault. Incomplete submissions or missing information may cause delays in processing and could result in your claim being declined.

Costs from third-party inspections or repairs are not covered unless approved in writing by KickAss.

YOUR RIGHTS UNDER ACL

This warranty is provided in addition to your rights under the Australian Consumer Law. You may be entitled to a replacement or refund for major failures, and to compensation for other reasonably foreseeable loss or damage.

Need Help?

Product Support: support@kickassproducts.com.au

Warranty Claims: warranty@kickassproducts.com.au

Customer Support Portal: supportportal.kickassproducts.com.au



KickAss is a registered trademark of
KickAss Products Pty Ltd.

Designed & imported by
KickAss Products Pty Ltd
39 Iris Place, Acacia Ridge, QLD 4110
Australia

Made in China

